Guidance: **Hygipod** IPS **Joining multiple Hygipods**

Please refer to your technical drawing to see which Hygipods return to the wall vs. connect to another Hygipod. This example is the partial installation process for a Doc M package.

Hygipod return to Hygipod join





When a return is used to connect a Hygipod to another, drill a pilot hole through one to ensure a tight connection between units.



Ensuring the Hygipod is aligned correctly, secure in place using a 4 x 30 mm screw. Secure at the top, middle and bottom.



Hygipod bracket to Hygipod join

One product family, one hygienic finish $\mid TROVEX$

